

**FLEET MANAGEMENT
POLICY / PROCEDURE**

SUBJECT: TO FUEL EQUIPMENT WITH RNI2000

APPROVED: Marilyn L Rawlings
MARILYN L RAWLINGS, FLEET MANAGER

DISTRIBUTION:

**Fleet Management
Fueling Sites (Listed Below)**

PURPOSE:

To establish guidelines on how to fuel equipment with the RNI2000 automated ring systems.

RNI2000 FUELING LOCATIONS:

The RNI2000 key readers and automated ring systems are located on the fuel islands at the following locations:

Fleet Management 2955 Van Buren Street Fort Myers, FL 33916	Unleaded and DYED Diesel
Billy's Creek - Depot 7 - 5560 Zip Drive Fort Myers, FL 33907	Unleaded and DYED Diesel
Evergreen Facility - Depot 1 190 Evergreen Road North Fort Myers, FL 33903	Unleaded and DYED Diesel
Government Complex - Pine Ridge Rd 15650 Pine Ridge Road Fort Myers, FL 33932	Unleaded and GOLD Diesel
Lehigh Acres 6501 Felix Romano Ave., Lehigh Acres, FL 33905	Unleaded and DYED Diesel

Lee County School Board –
14701 Six Mile Cypress Pkwy Fort Myers, FL 33912

Unleaded and GOLD Diesel

Lee County School Board
Mariner High School Chiquita Blvd. Cape Coral, FL 33993

Unleaded and GOLD Diesel

Lee County School Board
3291 Buckingham Road Fort Myers, FL 33905

Unleaded and GOLD Diesel

Lee County School Board
Williams Road Estero, FL 33928

Unleaded and GOLD Diesel

PROCEDURE FOR HANDS FREE -RNI2000 AUTOMATED RING SYSTEM:

RNI FUEL RING is the ring installed around the fuel inlet on a piece of equipment. It is used to transmit information from the equipment to the RNI fuel system.

Drive up to the fuel pump. Remove the hose, flip the handle up to start the pump, insert the nozzle into the fill tank and begin pumping the fuel.

The nozzle reads the ring on the fuel tank. The information received (vehicle number, odometer, etc.) will be stored in the RNI System until the information is retrieved. Keep the dispenser nozzle as close to the RNI ring as possible to receive information from ring. If connection is broken a new transaction is started and may flag system. When you are finished fueling, flip the handle down, place the nozzle back in the cradle, and replace the hose on the island. Do not leave hoses lying across drive ways. The fueling transaction is complete.

The information at each fuel site will be retrieved and reconciled daily.

Revision Date: June 2011